



Availability of lemo
connectors in Attila's office


Fixed plugs




FAA




FAN



FAB




FPA



FPL

Elbow plugs




FLC



FLS, FLV

Straight plugs




FFA




FFA



FFA



FFC




FFC




FFY



FFE



FFF




FFS


200 + 40

Different cable size


Fixed sockets




ERA, ERE




ERN




ERC




ERT




ERX




ECP



EHP



ELP




EPA, EPB, EPC



60

150

Elbow sockets



EPL, EPM, EPK, EPR



EPS



EPN




EPY

Plugs with resistor




FRT




FLR


Socket with microswitch



Free sockets




PCA




PCS


Fixed sockets



PSA



PSS



PES




PFS




PLK

Fixed coupler



RAD

20




RMA


Free coupler

50

Straight and elbow plugs with socket



FTR



FTA

10




FTL

50




FTY




ABA Adaptor from LEMO socket to BNC plug
~100pc

Part number	Weight (g)
ABA.00.250.NTL	18.7



ABC Adaptor from LEMO socket to BNC socket

Part number	Weight (g)
ABC.00.250.NTM	17



ABD Adaptor from LEMO socket to BNC fixed socket
~5pc

Part number	Weight (g)
ABD.00.250.NTM	21.4

P7 Panel cut-out (page 38)